



A330 Endorsement Crew Buddy Revision Sheet

Item	A330-200 _{D/L} + A330-300	
Evacuation & Lighting		
Emergency Evac Signal	Flight Deck + L1	
Emergency Light Switch	Flight Deck + L1	
Emergency Lighting	Approx 10 Mins	
Oxygen		
PSU Oxygen	15 Mins minimum	
PSU Activation	Pull Mask = Oxygen to all masks in that PSU	
PSU Shut Off	Can NOT be shut off	
Rafts		
Slide Raft Capacity	60 - 80 Passengers	
Sea Anchor	Girt Bar End (Manuall Deployed)	
Survival Kit	Water Girt Bar End	
Canopy	<ul style="list-style-type: none"> -In water at the girt bar end of the raft -Match Numbers to Pillar Number -Match 'Door End' words with door end of raft -Support Pillars found in separate bag 	
Raft Disconnect	<ul style="list-style-type: none"> -Lift the Girt Bar flap -Pull the exposed handle -Release the mooring line 	
Communications		
Emergency Call Indications	<ul style="list-style-type: none"> -3x HI/LO Chimes -Flashing Pink Light -AIP Red STEADY light + Text 'CALL PRIO CALL' 	
Emergency Call	PRIO ALL	
Emergency Call to Flight Deck	PRIO CAPT	
Emergency PA	PTT	
Normal PA to all areas except Crew Rest	PA + ALL + PTT	
Normal Call to Flight Deck	CAPT	
Cabin Ready	Cabin Ready button on FAP	
Additional Attendant Panels (AAP)	A330-200 L2 + L4	A330-300 L2, L3 + L4
Lavatory Smoke Indications	HI Chimes, ACP Amber FLASHING , AIP Red FLASHING , AIP Text of affected LAV, Smoke Screen appears on FAP, SMOKE LAV illuminates on AAP's.	
Emergency Equipment		
	A330-200	A330-300
Beacon	L1 406SE Land = XMT / Ditch = ARM Flashing LED visable after 10 seconds	
First Aid Kits	L1 + L2 + L4	
Megaphones	L1 + L4	
One Stop Shop (Defib, Phys Kit, Flexi Cuffs, SAAP, DG's Kit)	R2	
Emergency Galley Switch Location	All Galleys	
Infant Seat Belts	L2 (22)	L3 (22)
Infant Lifejackets	L2	L3
Extra BCF	R4 Station	Doors 2 Galley
Tech Crew Rest		
Crew Member responsible for pre-flight checks	L2P	R1P
Permitted to be occupied for Taxi, Take-off & Landing	No	Yes, with door open

Version 1.2 – 25th March 2021

